

High Intensity SS Strip Film Viewer Model HII-1

**The most specified film viewer
for industrial radiography,
the HII-1 from Quality NDE
is designed to provide the ultimate
in Hi-Intensity Illuminator**



NOW WITH NEW OVERHEAT AUTOMATIC SHUT DOWN PROTECTION

The viewer will shutdown automatically when temperature rises to 210°F (116°C) and will restart at 180°F (100°C)

**Will prevent from burning the
plexiglass viewing window**

Specifications:

- Manufactured in 304 Stainless Steel
- 1000 Watts produced by 4 BBA #1 Photo-flood bulbs
- Fan cooled
- Over heat protection
- Dimmer controlled
- Footswitch operated for on/off operation
- 4 Viewing masks: 70mm, 3½", 4½", 10" & 17"
- Reading light mounted on front
- Operates on 120 Volts/60 Hz AC
- Viewer size: 24" W x 10" H x 10" D

Operating Instructions:

- The master switch is off in the center position.
- For continuous light flip the master switch up.
- For intermittent light controlled by the foot switch, flip the master switch down.
- Always turn the switch off (center position) when the viewer is not in use as the fan operated continuously in both positions.

Replacement parts:

Use only # 1 Sylvania Photo flood bulbs

**Built to outlast
and outperform
all other viewers**

Maintenance:

- Replace bulbs when they appear black. DO NOT wait for bulb to burnout.
- To replace the bulbs, lift up front viewing area, unscrew bulbs and remove.
- CAUTION: Allow old bulbs to cool before touching. Always have the master switch off before placing hand inside.
- To replace the air filter, remove top panel, use care to avoid the sharp edges on the grille. Remove the dirty filter and replace it with a clean one.
- The filter must be changed regularly since an accumulation of dirt will cut down the air flow and result in overheating.

Authorized Representative

Quality NDE Limited

164, St-Jean-Baptiste
Mercier (Québec) J6R 2C2
Tel.: (450) 691-9090
Fax: (450) 691-6101
E-mail: info@qnde.ca

Web: www.qnde.ca